


SPARE PARTS CATALOGUE
: HUSQVARNA LC137I WITHOUT BATTERY AND CHARGER

Spare Parts List








SPARE PARTS LIST

LC 137i
HANDLE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	531146751	BAIL ARM ASSY		1	
2	531146758	HANDLE TUBE	UPPER HANDLE	1	
3	531146750	SEAT BRACKET ASSY		1	
4	531146749	SWITCHBOX ASSY		1	
5	531146757	WIRE	HANDLE CONTROL	1	
6	531146759	HANDLE TUBE	LOWER HANDLE	1	
7	531146762	KNOB ASSY	Knob	1	
8	599349379	CLIP	Cable Clip	1	
9	529596001	KNOB ASSY	Knob	2	
10	531146748	HANDLE SUPPORT ASSY		1	

LC 137i
POWER HEAD




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	531146731	COVER KIT	BATTERY LID KIT	1	
2	501490101	KEY		1	
3	531146733	BATTERY BOX		1	
4	531146732	WIRE	WIRE KIT	1	
5	531146734	MOTOR KIT	500W, 36V, BLDC, Single Phase	1	
6	531146735	CONTROL		1	
7	531146736	COVER KIT	POWER UNIT LOWER COVER	1	
8	531146742	INSTALLATION KIT		1	
9	531146741	BLADE SUPPORT		1	
10	529441701	BLADE		1	

LC 137i
GRASS BAG




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	531146755	HOLDER	GRASSBAG HOLDER	1	
2	531146756	GRASSBAG		1	

LC 137i
ACCESSORIES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	599831201	MULCH KIT		1	
2	529441610	BLADE		1	

LC 137i
DECK



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	531146746	FLAP	REAR FLAP	1	
2	531146761	PLUG	RUBBER PLUG	1	
3	531146744	CHASSIS		1	
4	531146743	COVER KIT	BELT PROTECTION COVER	1	
5	531146747	HEIGHT ADJUSTER		1	
6	531146739	WEIGHT		1	
7	531146740	COVER KIT	BASE COVER	1	
8	531146754	SPRING		1	
9	531146745	BAR	STRENGTH BAR	1	
10	531146753	CONNECTION ROD		1	
11	599349422	WHEEL	REAR WHEEL	1	
12	531146752	AXLE	REAR AXLE	1	
13	531146737	WHEEL KIT		1	
14	531146738	AXLE	FRONT AXLE	1	